

## Package contents



### This package contains:

- Stylus pen
- AC/DC power adapter
- AC plugs
- Battery pack
- Hand strap
- Quick reference manual
- Belt clip
- LCD screen protector
- USB ActiveSync cable
- Regulatory sleeve
- EULA sleeve

## Product overview

### Front



## Product overview

### Back



## Keyboard



- ESC** - Cancel current entry or action
- BKSP** - Clear last entered digit or symbol
- ENT** - Enter key
- SCAN** - Starts barcode scanning
- Navigation key** - Navigates through interface
- F1 - F11** - Programmable functional keys
- 1 - 0** - Digit keys
- .** - Inserts dot sign

**SP** - Inserts space

**Red key** - Access special characters

**Blue key** - Access 2nd level functions

**ALPHA** - Changes letters case and switches between digits and letters

**Blue key + windows key** - Suspends or wakes up device (Press Blue key first)

## HANDY TERMINAL Quick Reference Manual

Delfi Nova

## Getting Started

### 1. Open the cover



Slide the lockers upwards and remove the cover by pulling on it with your finger.

## Getting Started

### 2. MicroSD card



Micro SD Card is sold separately.  
Please contact your dealer.  
Micro SD Card is supported up to 32GB.


## Getting Started

### 3. Insert the battery

First, insert the battery into the battery well with the labels facing upward.  
Close the cover from the bottom and push down the cover until it locks properly.



### 4. Attach the plug 5. Charge the battery



Using AC/DC Power Adapter