

Factory Default



USB HID



Keyboard PS2



USB COM



RS232



Country Nordic

Enter configuration

1



Country

2




1

3



2

4



Exit configuration

5



Suffix selection



Enter configuration



Suffix



None



Return



TAB



Exit configuration